

SVAN 945A

SOUND LEVEL METER / ANALYSER

USER'S MANUAL

SVANTEK Ltd.

WARSAW, July 2002

CONTENTS

1. INTRODUCTION	1 - 1
<i>Main features of the SVAN 945A</i>	1 - 2
2. MANUAL CONTROL OF THE INSTRUMENT	2 - 1
2.1. CONTROL PUSH-BUTTONS ON THE FRONT PANEL	2 - 1
2.2. INPUT AND OUTPUT SOCKETS OF THE INSTRUMENT	2 - 3
3. SETTING OF THE INSTRUMENT	3 - 1
3.1. BASIS OF THE INSTRUMENT'S CONTROL	3 - 1
3.2. POWERING OF THE INSTRUMENT	3 - 14
3.2. INITIAL SETUP OF THE INSTRUMENT	3 - 14
4. MEASUREMENT FUNCTIONS OF THE INSTRUMENT	4 - 1
4.1. CALIBRATION	4 - 3
<i>Calibration procedure of the instrument</i>	4 - 3
4.2. SOUND LEVEL METER	4 - 5
<i>One profile mode of measurement results presentation</i>	4 - 7
<i>3 PROFILES mode of measurement results presentation</i>	4 - 8
<i>Presentation of the statistical analysis results - STATISTICS</i>	4 - 9
<i>Presentation of time history - PLOT</i>	4 - 9
4.1.1. Measurement parameters setting	4 - 11
<i>Measurement parameters setting - INPUT list</i>	4 - 11
<i>Selection of measurement parameters - MEASURE SETUP sub-list</i>	4 - 11
<i>Setting time delay before the start of measurements - START DELAY position</i>	4 - 11
<i>Setting the integration time - INT. TIME position</i>	4 - 11
<i>Setting number of repetition of measurement cycles - REP. CYCLE position</i>	4 - 13
<i>Setting time between two writings to the buffer's file - BUF. STEP position</i>	4 - 13
<i>Setting parameters in profiles - PROFILES SETUP sub-list</i>	4 - 14
<i>Setting parameters in a profile - PROFILE x sub-list</i>	4 - 14
<i>Selection of the weighting filter in SLM - FILTER position</i>	4 - 14
<i>Selection of the RMS detector - DETECTOR position</i>	4 - 15
<i>Selection of the SLM result to be saved in the buffer's file - BUFFER position</i>	4 - 15
<i>Selection of the measurement range in SLM - RANGE position</i>	4 - 16
<i>Selection of mode and parameters of triggering - TRIGGER SETUP sub-list</i>	4 - 16
<i>Switching the triggering on and off - TRIGGER position</i>	4 - 17
<i>Selection of the triggering signal - SOURCE position</i>	4 - 18
<i>Setting the level of triggering - TRG. LEVEL position</i>	4 - 18
4.3. ACTIVATION OF OPTIONAL FUNCTIONS	4 - 22
4.4. 1/1 OCTAVE ANALYSER	4 - 23
<i>Selection of the measurement range in 1/1 OCTAVE analysis - RANGE position</i>	4 - 26

<i>Selection of 1/1 OCTAVE analysis parameters - SPECTRUM sub-list</i>	4 - 27
<i>Selection of the weighting filter in 1/1 OCTAVE analysis - FILTER position</i>	4 - 27
<i>Selection of 1/1 OCTAVE analysis result to be saved in the buffer's file - BUFFER position</i>	4 - 28
4.5. 1/3 OCTAVE ANALYSER	4 - 29
<i>Selection of the measurement range in 1/3 OCTAVE analysis - RANGE position</i>	4 - 32
<i>Selection of 1/3 OCTAVE analysis parameters - SPECTRUM sub-list</i>	4 - 33
<i>Selection of the weighting filter in 1/3 OCTAVE analysis - FILTER position</i>	4 - 33
<i>Selection of 1/3 OCTAVE analysis result to be saved in the buffer's file - BUFFER position</i>	4 - 34
5. AUXILIARY FUNCTIONS	5 - 1
5.1. DATA AVAILABLE ON THE SCREEN – DISPLAY LIST	5 - 1
<i>Selection of the modes of measurement results presentation – DISPLAY MODES sub-list</i>	5 - 1
<i>Selection of the scale in graphical results presentation – DISPLAY SCALE sub-list</i>	5 - 3
<i>Scaling of the vertical axis of the graphical presentation – DYNAMIC position</i>	5 - 3
<i>Scaling of the horizontal axis of the graphical presentation – X-ZOOM position</i>	5 - 3
<i>Selection of the buffer's file to the screen presentation – BUFFER VIEW sub-list</i>	5 - 3
<i>Checking the state of the internal battery – BATTERY position</i>	5 - 6
<i>Setting the contrast of the screen – CONTRAST position</i>	5 - 7
<i>Setting the backlight parameters – BACKLIGHT sub-list</i>	5 - 7
<i>Automatic switch off of the backlight – TIMEOUT position</i>	5 - 8
<i>Setting the brightness of the backlight – BRIGHTNESS position</i>	5 - 8
<i>Checking specification of the instrument – UNIT LABEL position</i>	5 - 8
5.2. SETUP MENU	5 - 10
<i>Programming of the instrument's internal timer – TIMER position</i>	5 - 11
<i>Programming of the instrument's internal Real Time Clock – RTC position</i>	5 - 11
<i>Setting the parameters of the serial interface – RS232 sub-list</i>	5 - 12
<i>Setting the transmission speed of the serial interface – BAUD RATE position</i>	5 - 12
<i>Setting time limit for the performance of serial interface operation – TIME OUT position</i>	5 - 13
<i>Selection of the microphone parameters – MICROPHONE sub-list</i>	5 - 13
<i>Setting the polarisation voltage of the microphone – POL.VOLTAGE position</i>	5 - 13
<i>Switching on or off the compensating filter – COMP. FILTER position</i>	5 - 14
<i>Setting the conditions for the diffuse field measurements – FIELD CORRECTION position</i>	5 - 14
<i>Introduction the filter coefficients for 1/3 (1/1) OCTAVE analysis – USER FILTERS sub-list</i>	5 - 15
<i>Selection of few push-button's mode – SHIFT MODE sub-list</i>	5 - 16
<i>Selection of the working mode of <SHIFT> push-button – SHIFT position</i>	5 - 16
<i>Selection of the working mode of <START / STOP> push-button – ST/SP position</i>	5 - 16
<i>Return to the factory made settings – CLEAR SETUP position</i>	5 - 17
<i>Selection of detector's type in the LEQ calculations – LEQ INTEGRATION position</i>	5 - 17
<i>Selection of the warnings – WARNINGS sub-list</i>	5 - 18
<i>Saving the measurement results in a file – RES.NOT SAVE position</i>	5 - 18
5.3. SAVING THE MEASUREMENT RESULTS	5 - 20
<i>Saving files</i>	5 - 20

<i>Selection of the file's operation – FILE list</i>	5 - 21
<i>Saving files in the instrument's memory – SAVE and SAVE NEXT positions</i>	5 - 22
<i>Controlling the data storing in the instrument's memory – SAVE OPTIONS sub-list</i>	5 - 25
<i>Replacement of the existing files by the new ones – REPLACE position</i>	5 - 25
<i>Controlling of the measurement statistics savings – SAVE STAT. position</i>	5 - 26
<i>Controlling of the measurement results savings – AUTO SAVE position</i>	5 - 26
<i>Loading the files with the measurement results – LOAD position</i>	5 - 27
<i>Removing a file with the measurement results from memory – DELETE position</i>	5 - 28
<i>Removing all files with measurement results from memory – DELETE ALL position</i>	5 - 30
<i>Removing all files with results from buffer's memory – CLEAR BUFFER position</i>	5 - 30
<i>Checking the contents of the memory – CATALOGUE position</i>	5 - 31
<i>Checking the free space in the memory – FREE SPACE position</i>	5 - 32
<i>Operations in buffer</i>	5 - 32
5.4. PRINTING REPORTS	5 - 34
<i>Edition of the user's text to be added to the reports – TITLE position</i>	5 - 35
<i>Printing of the measurement results – PRINT RESULTS position</i>	5 - 35
<i>Printing of the file's catalogue – PRINT CATALOGUE position</i>	5 - 36
<i>Printing of the statistics of measurement results – PRINT STATISTICS position</i>	5 - 37
<i>Printing of the measurement results from the selected file – PRINT FILE position</i>	5 - 38
<i>Printing of the results from the selected buffer's file – PRINT BUFFER position</i>	5 - 39
<i>Selection of the printing options – OPTIONS sub-list</i>	5 - 41
<i>Selection of the format of the print out – FORMAT position</i>	5 - 41
<i>Controlling the paper ejection after print out – EJECT P. position</i>	5 - 41
<i>Selection of the language of the printed report – LANGUAGE position</i>	5 - 42
 APPENDIX A. REMOTE CONTROL	 A - 1
INPUT / OUTPUT TRANSMISSION TYPES	A - 1
FUNCTION #1 – INPUT / OUTPUT OF THE CONTROL SETTING CODES	A - 1
FUNCTION #2 – READ OUT OF THE MEASUREMENT RESULTS IN THE SLM MODE	A - 2
FUNCTION #3 – READ OUT OF THE MEASUREMENT RESULTS IN 1/1 OCTAVE & 1/3 OCTAVE MODE	A - 3
FUNCTION #4 – READ OUT OF THE DATA FILE FROM THE INTERNAL FLASH DISC	A - 4
FUNCTION #5 – READ OUT OF THE STATISTICAL ANALYSIS RESULTS	A - 5
CONTROL SETTING CODES	A - 6
 APPENDIX B. DATA FILE STRUCTURES	 B - 1
B.1. GENERAL STRUCTURE OF THE SVAN 94x FILE	B - 1
B.2. STRUCTURE OF THE FILE WITH THE RESULTS FROM THE SLM MODE	B - 9
B.3. STRUCTURE OF THE FILE WITH 1/1 OCTAVE ANALYSIS RESULTS	B - 9
B.4. STRUCTURE OF THE FILE WITH 1/3 OCTAVE ANALYSIS RESULTS	B - 9

B.5. STRUCTURE OF THE FILE WITH THE TONALITY FUNCTION RESULTS	B - 10
B.6. STRUCTURE OF THE FILE WITH FFT ANALYSIS RESULTS	B - 10
B.7. STRUCTURE OF THE FILE CONTAINING RESULTS FROM BUFFER'S FILE	B - 10
B.7.1. The contents of the files in the buffer	B - 10
B.7.1.1. Record with the results	B - 11
B.7.1.2. Record with the state of the markers	B - 11
B.7.1.3. Records with the breaks in the results registration	B - 12
APPENDIX C. TECHNICAL SPECIFICATION	C - 1
C.1. SOUND LEVEL METER SPECIFICATION	C - 1
C.2. SOUND ANALYSER SPECIFICATION	C - 8
C.3. AUXILIARY TECHNICAL SPECIFICATION	C - 12
APPENDIX D. DEFINITIONS AND FILTER CHARACTERISTICS	D - 1
D.1. DEFINITIONS AND FORMULAE	D - 1
D.2. CHARACTERISTICS OF DIGITAL FILTERS IMPLEMENTED IN SVAN 945A	D - 4



Notice: *This user's manual presents the software version named 3.01 (cf. the description of **UNIT LABEL** position of **DISPLAY** list). The succeeding software versions (marked with the bigger numbers) can slightly change the view of some screens presented in the text of the manual.*

INDEX OF LISTS, SUB-LISTS AND POSITIONS

1/1 OCTAVE	<i>Selection of 1/1 OCTAVE analysis, position of FUNCTION sub-list</i>	4 - 23
1/3 OCTAVE	<i>Selection of 1/3 OCTAVE analysis, position of FUNCTION sub-list</i>	4 - 29
3 PROFILES	<i>Measurement results presentation mode (numerical), position of DISPLAY sub-list</i>	5 - 1
AUTO SAVE	<i>Controlling of measurement results savings, position of SAVE OPTIONS sub-list</i>	5 - 26
BATTERY	<i>Checking the state of the internal battery, position of DISPLAY list</i>	5 - 6
BAUD RATE	<i>Setting the transmission speed of the serial interface, position of RS232 sub-list</i>	5 - 12
BUF. STEP	<i>Setting time between two writings to the buffer's file, position of MEASURE SETUP sub-list</i>	4 - 13
BUFFER	<i>Selection of the SLM result to be saved in the buffer's file, position of PROFILE x sub-list</i>	4 - 15
BUFFER	<i>Selection of 1/1 OCTAVE analysis result to be saved in the buffer's file, position of SPECTRUM sub-list</i>	4 - 28
BUFFER	<i>Selection of 1/3 OCTAVE analysis result to be saved in the buffer's file, position of SPECTRUM sub-list</i>	4 - 34
BUFFER VIEW	<i>Selection of the buffer's file to the screen presentation, sub-list of DISPLAY list</i>	5 - 3
CAL. LEVEL	<i>Setting the level of the calibrator's signal, position of CALIBRATION sub-list</i>	4 - 3
CALIBRATION	<i>Calibration of sound measurement channel, sub-list of FUNCTION list</i>	4 - 3
CATALOGUE	<i>Controlling the contents of the memory, position of FILE list</i>	5 - 31
CLEAR BUFFER	<i>Removing all files with the results from buffer's memory, position of FILE list</i>	5 - 30
CLEAR SETUP	<i>Return to the factory made settings, position of SETUP list</i>	5 - 17
COMP. FILTER	<i>Switching on or off the compensating filter, position of MICROPHONE sub-list</i>	5 - 14
CONTRAST	<i>Setting the contrast of the screen, position of DISPLAY list</i>	5 - 7
DELETE	<i>Removing a file with the results from instrument's memory, position of FILE list</i>	5 - 28
DELETE ALL	<i>Removing all files from instrument's memory, position of FILE list</i>	5 - 30
DETECTOR	<i>Selection of the RMS detector, position of PROFILE x sub-list</i>	4 - 15
DISPLAY	<i>Data available on the screen, main list (function of the push-button)</i>	5 - 1
DISPLAY MODES	<i>Selection of the ways of measurement results presentation, sub-list of DISPLAY list</i>	5 - 1
DISPLAY SCALE	<i>Selection of the scale in graphical results presentations, sub-list of DISPLAY list</i>	5 - 3
DYNAMIC	<i>Scaling of the vertical axis of the graphical presentation, position of DISPLAY SCALE sub-list</i>	5 - 3
ENTER CODE	<i>Access to optional functions</i>	4 - 22
EJECT P.	<i>Controlling the paper ejection after print out, position of OPTIONS sub-list</i>	5 - 41
FILE	<i>Available operations on files, main list (function of the push-button)</i>	5 - 21
FILE NAME	<i>Edition of the file name in which the measurement results has to be saved</i>	5 - 22
FILTER	<i>Selection of the weighting filter in SLM, position of PROFILE x sub-list</i>	4 - 14
FILTER	<i>Selection of the weighting filter in 1/1 OCTAVE analysis, position of SPECTRUM sub-list</i>	4 - 27
FILTER	<i>Selection of the weighting filter in 1/3 OCTAVE analysis, position of SPECTRUM sub-list</i>	4 - 33
FORMAT	<i>Selection of the format of the print out, position of OPTIONS sub-list</i>	5 - 41
FREE SPACE	<i>Checking the free space in the memory, position of FILE list</i>	5 - 32
FUNCTION	<i>Selection of the unit's measurement function, main list (function of the push-button)</i>	2 - 3
INPUT	<i>Measurement parameters setting, main list (function of the push-button)</i>	4 - 11
INT. TIME	<i>Setting the integration time, position of MEASURE SETUP sub-list</i>	4 - 11
LEQ INTEGRATION	<i>Selection of detector's type in the LEQ calculations, position of SETUP list</i>	5 - 17
LEVEL METER	<i>Selection of SLM function, position of FUNCTION sub-list</i>	4 - 5
OPTIONS	<i>Selection of the printing options, sub-list of REPORT list</i>	5 - 41
MEASUR. FUNCTION	<i>Selection of the available measurement function, sub-list of FUNCTION list</i>	4 - 5
MEASURE SETUP	<i>Selection of measurement parameters, sub-list of INPUT list</i>	4 - 11
MICROPHONE	<i>Selection of the parameters of the microphone, position of SETUP list</i>	5 - 13

POL. VOLTAGE	<i>Selection of microphone's polarisation voltage, position of MICROPHONE sub-list</i>	5 - 14
PLOT	<i>Measurement results presentation mode (graphical), position of DISPLAY MODES sub-list</i>	5 - 1
PRINT BUFFER	<i>Printing of the results from the selected buffer's file, position of REPORT list</i>	5 - 39
PRINT CATALOGUE	<i>Printing of the file's catalogue, position of REPORT list</i>	5 - 36
PRINT FILE	<i>Printing of the measurement results from the selected file, position of REPORT list</i>	5 - 38
PRINT RESULTS	<i>Printing of the measurement results, position of REPORT list</i>	5 - 35
PRINT STATISTICS	<i>Printing of the statistics of measurement results, position of REPORT list</i>	5 - 37
PROFILE x	<i>Setting parameters in a profile of SLM, sub-list of PROFILES SETUP sub-list</i>	4 - 14
PROFILES SETUP	<i>Setting parameters in profiles and for octave analysis, sub-list of INPUT list</i>	4 - 14
RANGE	<i>Selection of the measurement range in SLM, position of INPUT list</i>	4 - 16
RANGE	<i>Selection of the measurement range in 1/1 OCTAVE analysis, position of INPUT list</i>	4 - 26
RANGE	<i>Selection of the measurement range in 1/3 OCTAVE analysis, position of INPUT list</i>	4 - 32
REP. CYCLE	<i>Setting number of repetition of measurement cycles, position of MEASURE SETUP sub-list</i>	4 - 13
REPLACE	<i>Replacement of the existing files by the new ones, position of SAVE OPTIONS sub-list</i>	5 - 25
REPORT	<i>Printing reports, main list (function of the push-button)</i>	5 - 34
RS232	<i>Setting the parameters of the serial interface, sub-list of SETUP list</i>	5 - 12
RTC	<i>Programming of the instrument's internal Real Time Clock, position of RTC sub-list</i>	5 - 11
SAVE	<i>Saving files in the instrument's memory, position of FILE list</i>	5 - 22
SAVE NEXT	<i>Saving files in the memory with the name's modification, position of FILE list</i>	5 - 22
SAVE OPTIONS	<i>Controlling of the data storing in the instrument's memory, sub-list of FILE list</i>	5 - 25
SAVE STAT.	<i>Controlling of the statistics savings, position of SAVE OPTIONS sub-list</i>	5 - 26
SETUP	<i>Settings of the instrument's parameters, main list (function of the push-button)</i>	5 - 10
SHIFT	<i>Selection of the working mode of <SHIFT> push-button, position of SHIFT MODE sub-list</i>	5 - 16
SHIFT MODE	<i>Selection of few push-button's mode, sub-list of SETUP list</i>	5 - 16
SOURCE	<i>Selection of the triggering signal, position of TRIGGER SETUP sub-list</i>	5 - 16
SPECTRUM	<i>Measurement results presentation mode (graphical), position of DISPLAY sub-list</i>	5 - 1
SPECTRUM	<i>Selection of 1/1 OCTAVE analysis parameters, sub-list of PROFILES SETUP sub-list</i>	4 - 27
SPECTRUM	<i>Selection of 1/3 OCTAVE analysis parameters, sub-list of PROFILES SETUP sub-list</i>	4 - 33
ST/SP	<i>Selection of the working mode of <START / STOP> push-button, position of SHIFT MODE sub-list</i>	5 - 16
START DELAY	<i>Setting start delay before the start of measurement, position of MEASURE SETUP sub-list</i>	4 - 11
STATISTICS	<i>Measurement results presentation mode (graphical), position of DISPLAY sub-list</i>	5 - 1
TIME OUT	<i>Setting time limit for the performance of serial interface operation, position of RS232 sub-list</i>	5 - 13
TIMER	<i>Programming of the instrument's internal timer, position of SETUP list</i>	5 - 11
TITLE	<i>Edition of the user's text to be added to the reports, position of REPORT list</i>	5 - 35
TRG. LEVEL	<i>Selection of the triggering mode, position of TRIGGER SETUP sub-list</i>	4 - 18
TRIGGER	<i>Switching triggering on and off, position of TRIGGER SETUP sub-list</i>	4 - 17
TRIGGER SETUP	<i>Selection of mode and parameters of triggering, sub-list of INPUT list</i>	4 - 16
UNIT LABEL	<i>Checking specification of the instrument, position of DISPLAY list</i>	5 - 8
USER FILTERS	<i>Introduction of 1/3 octave filter coefficients, sub-list of SETUP list</i>	5 - 15
X-ZOOM	<i>Scaling of the horizontal axis of the graphical presentation, position of DISPLAY SCALE sub-list</i>	5 - 3